

# **BabyWheelEasy**

## **Setup Guide and User Instructions**



The 'Car Seat Retainer' is supplied with two 'seat retainer' set screws for fitting the 'Car Seat Retainer' in the correct position on the 'Car Seat Retainer Frame' for your particular car seat.



The green arrows indicate the seat retainer set screw location positions, there are six preset position, of which one is used depending on your car seat model



Once you have established the best fit position for your 'carry car seat' insert the two 'seat retainer' screws to secure the 'seat retainer' in a fixed position - Seat Retainer positioning is explained in greater detail on pages 6 and 7



The green arrow indicates the 'Car Seat Retainer' set screw location on the 'Car Seat Retainer Frame', which is fixed to the BabyWheelEasy telescopic extending handle.



Lay the BabyWheelEasy on a flat surface and then lay the back of your car seat on the rails of the BabyWheelEasy telescopic handle.

Without inserting the 'Seat Retainer' set screws push the 'Seat Retainer' down into The 'Seat Retainer Frame', as indicated by the red arrows, so the 'Seat Retainer' pushes firmly against the car seat.



Having identified the 'best fit' position for the 'Seat Retainer' set screws for your car seat, as discribed on page 7, insert the set screws in the relevant preset set screw position.



'Seat Retainer' fixed to 'Seat Retainer Frame'



Loosen the thumb screws on the side of the 'Seat Retainer Frame' as indicated by the blue arrows, by loosening these thumb screws the 'Seat Retainer Frame' is free to move up and down the BabyWheelEasy handle.



The 'Seat Retainer Frame' is free to slide up and down the BabyWheelEasy handle assembly to enable the 'Seat Retainer' and 'Seat Retainer Frame' to firmly secure your car seat



Lay the BabyWheelEasy on a flat surface and then lay your car seat on the handle rails and slide the 'Seat Retainer Frame' down onto the car seat



When tightening thumb screws (red arrows) ensure pressure is maintained in the direction of the blue arrow whilst making sure the base of the car seat is located on the curve of the BabyWheelEasy base.



While maintaining a downward pressure with one hand, in the direction of the blue arrow, tighten the thumb screws, as indicated by the red arrows.



Day-to-day fitting of your car seat to your BabyWheelEasy.  
Lay your BabyWheelEasy on the floor or flat surface, place the top of your car seat under the 'Seat Retainer' (green arrow) and ensure the base of the car seat is sitting in the curve of the base of the BabyWheelEasy (red arrow).



Place the 'male' end of the BabyWheelEasy tension strap between the car seat and the car seat carry handle (see green arrow)



Connect the 'male' connector into the 'female' connector of the BabyWheelEasy tensioning strap (see green arrow) - repeat on the other strap.



Connect the 'male' connector into the 'female' connector of the BabyWheelEasy tensioning strap (see green arrow) - repeat on the other strap.



**Pull both BabyWheelEasy tension straps in the direction of the red arrow until tight**



Ensure that the 'Seat Retainer' (top green arrow) is over the top of your car seat. Ensure the base of the car seat is located in the 'curve' of the BabyWheelEasy base (bottom green arrow). Ensure the tension retaining straps are pull tight (see red arrow)



Extend the BabyWheelEasy handle and roll away....